


## CB RADIO OR CAR PHONE

When installing large capacity wireless equipment or a car phone in your DATSUN, be sure to observe the following as it may adversely affect the E.F.I. system and other electronic parts depending on its installation location.

- Keep the antenna as far as possible away from the Electronic Control Unit.
- Also keep the antenna feeder line as far as possible away from the E.F.I. harness [7.9 in (20 cm) min.]. Do not make them parallel for a long distance.
- Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
- For details, consult a NISSAN/DATSUN dealer or other competent service facility.

## CLOCK



The time is displayed when the ignition switch is in the "ACC" or "ON" position. The clock continues operation even when the switch is set in "OFF" or "LOCK", though the time is not displayed. This digital clock is able to display the time in hours and minutes, or the day (month and date), or it can display minutes and seconds by controlling the control knob, thus being used as a stop watch.

### Calendar display

With the time in hours and minutes displayed, turn the control knob clockwise; the month and date will be displayed for a few seconds. After that, display of time will be restored.

The month and date are expressed in numerals.

(Example)

12 26

Month Date

The meanings of the numerals for the months are:

1: January	7: July
2: February	8: August
3: March	9: September
4: April	10: October
5: May	11: November
6: June	12: December

### Minute-second display

With the time in hours and minutes displayed, turn the control knob clockwise twice; the minute and second will then be displayed. To restore the hour and minute display, turn the knob once clockwise.

### Stop watch

With the hour and minute displayed, turn the control knob once counterclockwise, and the clock may be used as a stop watch. Depress the knob to start counting, and depress it again to stop counting; the counted time will be displayed. To reset the display to "00:00", turn the knob clockwise when the stop watch is not counting.