


1995 - 1998 Toyota 4runner (Hilux) Clock removal instructions

1. Check the dome-light. If the dome light is not working, check the dome light fuse, the light and clock are on the same circuit.



2. Remove the knobs and dials pulling straight out.

3. Using a thin knife, spatula, or flathead screwdriver, carefully pry off the heat and AC face plate. The AC power button will pop as you gently move around the face plate



4. Remove the 2 phillips head screws.

5. Pull the center console from the dashboard, it helps gently pop a top corner and work your way around the console. The bottom portion will remain attached but you can access the clock at this point.

6. Unplug all 3 wiring harnesses; hazard switch, rear defrost, and clock.

7. With a thin bladed tool, gently pry the 4 tabs holding the clock in place.

That's it!

Send it off to www.autoclockrepair.com